

ON/OFF REMOTE CONTROLLER PAC-YT40ANRA

JUST PRESS A SWITCH TO START. ALL OF THE UNITS CAN BE ON/OFF BY PRESSING THE MAIN SWITCH, AND EACH UNIT IN THE GROUP CAN BE ON/OFF WITH INDIVIDUAL SWITCH. THE PAC-YT40ANRA ALSO HAS HARDWIRED CONNECTION AVAILABLE (ON/OFF INPUT, FIRE ALARM INPUT, RUN OUTPUT, FAULT OUTPUT).

FUNCTION	DESCRIPTION	PAC-YT40ANRA	
		OPERATIONS	DISPLAY
UNITS	Max No.Units	50 units/16 groups	
ON/OFF	Run and stop operation	✓	✓
ERROR INDICATION	LED flashes during failure. (The error code can be confirmed by removing the cover.)	-	✓
VENTILATION OPERATION (INDEPENDENT)	Group operation of only LOSSNAY units possible. *Only ON/OFF of group.	✓	✓
VENTILATION OPERATION (INTERLOCKED)	The LOSSNAY will run in interlock with the operation of indoor unit. *The fan rate and mode cannot be changed. The LED will turn ON only during operation after interlocking.	✓	✓
EXTERNAL INPUT	On/Off/Fire Alarm	✓	
EXTERNAL OUTPUT	On/Off/Faults		✓

• Dimensions: 5-1/8(W) x 4-23/32(H) x 3/4(D) in.
130(W) x 120(H) x 19(D) mm



- The group setting is kept in nonvolatile memory. No need to worry about re-setting at power failure.
- No individual AC power supply is needed. The power can be supplied from one outdoor unit (R410A) or Power supply unit.

SYSTEM EXAMPLE

