

## Mr. Slim Wireless Remote Controller Control and Functionality Features

The new M-Series wireless remote controllers offer easy to use complete control over your comfort.

Our wireless controller lets the user adjust the temperature instantly with one tap of a button. And the command language couldn't be easier. There's a button for TOO COOL and for TOO WARM!



### LCD Wireless Remote

The hand-held Mr. Slim LCD wireless remote controller is easier to use than most TV remotes. The set temperature display is large and easy to read. The convenient remote provides easy control of the Fan Speed and direction, as well as the Cool, Heat and Dry modes from anywhere in the room.



### 24 Hour On/Off Timer

Operation can be set to start or stop the system at a specified time and displays the remaining time on the LCD display.



### Fuzzy Logic – "I Feel Warm/Cold"

Fuzzy Logic "I Feel" control allows you to adjust room temperature more precisely with a simple touch of a button. Just press the "Too Warm" button if it's warmer than desired or the "Too Cool" if it's too cool. This unique feature is intelligent enough to memorize the desired temperature you've set and repeat it precisely every time. It also works to prevent excessive cooling or heating and thus helps to conserve energy.



### 5-Step Vane Control & Swing Mode

This intelligent air direction control can be adjusted by the touch of a button from the comfort of your chair. Using the remote controller, you can select from five airflow settings to match room layout and the location of people in the room. You can also activate the swing vane mode for automatic maximum coverage.






### Wide & Long Air-flow

You can easily adjust the horizontal airflow direction with your remote control. When you combine this control with the 5-step Vane and Long control, you can maximize the airflow coverage with up to 42 patterns.

The airflow can be extended as far as 12 metres (or 39 feet) to reach the far end of a very long living room or kitchen in open concept living areas and studios.



### Horizontal + Vertical Vane Control

With just a touch on your remote control, you can set the direction of both the horizontal and vertical vanes to your liking. Or simply set both to swing mode to deliver the air evenly across the room.



### Auto Mode

In Auto Mode the microprocessor automatically determines the horizontal vane angle and operation for the optimum room temperature distribution. Auto Vane is created to set the vane angle automatically and Auto Fan is created to adjust airflow speed automatically. Combined, these features allow the ideal room temperature to be achieved in the shortest amount of time.



### Auto Change Over

For heat pump models, the Auto Change Over function will automatically switch back and forth from cooling and heating to compensate for significant temperature changes in a room. This feature allows total hands-free comfort and efficient operation



### Auto Restart

This function is especially useful during sudden power interruptions and blackouts. It allows the system to memorize operation settings and then restore them after the system is automatically restarted once the power has been restored.

This allows you to sleep peacefully without having the bother of getting up and resetting your air-conditioner at night or worrying about outages while you are away from home.



### Powerful Cool or Powerful Mode

The automatic one-touch Powerful Cool ensures faster cooling. On some specific models, Powerful Mode is available to ensure faster heating and cooling. Whether you just came back from a sweaty sports event or been through a chilled snow-melting day, the system produces more airflow than the "high" fan speed, giving you a boost in heating or cooling for 15 minutes, and then automatically returning to the regular setting.